## Mounting and drilling template for lever frame and switch mounting bracket

## PLEASE BE SURE TO PRINT "ACTUAL SIZE"

Suitable piece of softwood - approx 55mm x 55mm by length to suit frame -6 x Pilot Holes to suit No 1 x 1/4" woodscrew  $\bigcirc$